





Mobilité électrique



Solutions de recharge



STATION DE CHARGEMENT DES VÉHICULES ÉLECTRIQUES


HOME

GUIDE DE DÉMARRAGE RAPIDE 2/2









COORDONNÉES DE CONTACT

Pour plus d'information ou accéder au service de dépannage,
veuillez contacter l'adresse électronique suivante :

contact@evlink.ch

N° de téléphone :

+41 842 000 842

EV LINK SA

Case postale

1026 Denges

Vaud

Suisse

www.evlink.ch

Version du document : 1.2

Date du document : 18.8.2020

2020 EV LINK. Tous droits réservés. EV LINK, le logo EV LINK et d'autres marques sont la propriété de EV LINK et peuvent être enregistrés. Toutes les autres marques sont la propriété de leurs propriétaires respectifs. EV LINK n'assume aucune responsabilité pour les erreurs qui pourraient apparaître dans ce manuel. Les informations contenues dans ce document peuvent être modifiées sans préavis.



DEEE : Ne jetez l'appareil qu'au centre de recyclage.

NOTES

This image shows a full page of a worksheet designed for handwriting practice. It consists of approximately 20 horizontal rows. Each row is defined by two parallel dotted lines, creating a series of uniform gaps for letter height. The entire page is otherwise blank, with no margins, text, or other markings.



Imprimé en Suisse sur
du papier recyclé